

MagicBox MIDI I/O Jack

parameter feedback to BCR

- 1 MIDI Current Source (+)
- 2 shield
- 3 MIDI Current Sink (Data)

MIDI IN

- 4 MIDI Current Source
- 5 MIDI Current Sink

MIDI Split Cable *male plug, solder side*



